




















DO'S & DON'TS CHECK LIST FOR SAFE SOLUTION® JOBS

DO'S

-  Ensure that all workers maintain approximately 2 metres (6 feet) distance between each other while working and they fully read the application instructions and understand application procedures.
-  Wear identifying Safe Solution® logo embroidered shirts or badges.
-  If possible, leave a one square foot untreated area in a corner for before and after reference and for future inspections (take a picture to remember where this untreated area is).
-  Where required, have appropriate safety gear onsite, including protective face masks, organic vapor masks, proper eye protection, protective gloves, eye wash, safety kit, etc (note: pool shower areas may emit irritating fumes when treating).
-  Walk-around and review any potential hazards. If an area should be avoided, tape it off to remind workers to stay clear – take your time and do quality work.
-  Tape any exposed metal kick plates, or other delicate surface types, that you may come up against when spraying, mopping, or when using floor machine.
-  Look carefully to identify any pre-existing stains or damaged tiles – take before and after pictures.
-  Ensure Safety Data Sheets “SDS” are onsite and available upon request.
-  Apply in approximately 100 sq. ft. sections with minimum two applicators working per section, stopping at marked grout joints, thresholds, or natural barriers (hint: use safety cones as barriers where needed).
-  Always leave the area cleaner and tidier than when you arrived.

DON'TS

-  Don't wear shorts or have exposed legs, ankles, or feet while on the job.
-  Don't walk off the area you are treating until Safe Solution® is completely neutralized.
-  DO NOT pour Safe Solution® directly onto the surface that you are treating.
-  Don't rush.
-  DO NOT SPRAY, MOP, OR SPLASH any solution onto walls, glass, metals, appliances, carpets or any other surface that you are treating (wipe up immediately if you do).
-  Don't allow the overlapping of treatment from treated area to untreated area.
-  DO NOT leave used floor machine and pad, doodlebug and pad, mops, treatment bottles or sprayers standing on surface areas, including on counter-tops, tables, and appliances (hint: use 20L (5G) pails to carry sprayers and 15L (15Qt) buckets to carry everything else).
-  Don't leave your buckets, mops, or sprayers messy or dirty when the job is complete.
-  DO NOT leave until you are fully satisfied and have given the work area one final walk around using the post job treatment area checklist.

